

Sunroof - Quick Start Guide

Congratulations on your new Sunroof!

Sunroof Operation

- Your sunroof has 3 buttons labeled “Vent”, “Close”, and “Open”.
- All of the buttons are activated by the “one touch” system. Simply press and release a button and the roof will perform the desired command.
- Your roof is designed to “auto-close” once your vehicle is shut off to both protect your vehicle from weather and the contents from being stolen.
- If you wish your roof to remain open after you’ve shut down your vehicle simply press any one of the three buttons that operate the roof. This will stop the glass from closing and re-open it fully.
- Some vehicles will experience a “buffeting” or “helicopter” like noise while driving with the roof open. Opening the rear windows about 2 inches will even out the pressure and alleviate the condition.
- Warranty on New Car Installation: Your sunroof carries a 3-year 36,000 mile non-transferable limited warranty as well as a 5-year 60,000 mile warranty on the parts only from the roof manufacturer.
- Warranty on Used Car Installation: Used cars will carry the balance of the 3-year 36,000 mile limited warranty OR a 1-year 12,000 mile limited warranty, whichever is greater.

Questions with your Sunroof?

Please call 508-832-9816

